DATA CENTER OPERATIONS BRANCH

NDS OPERATIONS PROCEDURE MANUAL NO. P-D005

SYSTEMS SW & HW 13 April 1983

DISC BOOTS

SYMBOLIC TITLE: DBOOT ORIGINATOR:

STAT

ADMINISTRATIVE-INTERNAL USE ONLY

Approved For Release 2008/02/28 : CIA-RDP94T00858R000601160001-5

DATA CENTER OPERATIONS BRANCH

DCOB OPERATIONS PROCEDURE MANUAL No. P-D

SYSTEM S/W & H/W 17 March 1983

DISC BOOTS

PURPOSE

1. This Manual provides guidelines for trainees and operators when setting an application for disc boots.

REFERENCES

2. N/A

PROCESSING

- 3. Whenever a disc boot is performed on the U1100/84 NDS, the following steps should be followed.
 - a. Load paths for each cluster should be established before any bootstrapping is done.
 - Cluster Ø, 1 or cross clustered
 - (2) CPU's in application
 - (3) IOU's in application
 - (4) MSU's in application
 - (5) SIU's in application
 - b. Maintenance mode switches used in configuration should be in off position.
 - Release panel lock.
 - d. Stop the processors in the application if not stopped.
 - e. Load path should be set to specify components in applications.
 - f. Application light for load path must be lighted (green).
 - g. Enable partition interface indicator must be lighted (green).
 - h. Enable manual load light must be lighted (yellow).

ADMINISTRATIVE-INTERNAL USE ONLY

DCOB OPERATIONS PROCEDURE MANUAL No. P-D

SYSTEM S/W & H/W 17 March 1983

- i. Check the DRS System Pack for disc string and unit.
- j. Set the channel/device/unit rotary switches on the IOU selected by the load path to point to system DRS boot device.
- k. Rotate the proc select rotary switch to the appropriate processor and set no jump keys for the disc boot unless a dump is needed.
 - 1. Under manual load, press clear then initial load.
- m. EXEC messages will be displayed at the operator's console. The console will be the lowest numbered console on-line at the SAU.
- n. Since booting from this device (DRS) the EXEC has already figured out which is the DRS pack.
- o. Refer to operators reference manual, procedure supplements, etc., for answering further EXEC messages.

STAT